



NOTES:

READ WATER TABLE DEPTH:

1. MEASURE DISTANCE FROM TOP EDGE OF RISER TO WATER SURFACE INSIDE OF PIPE.
2. MEASURE DISTANCE FROM TOP EDGE OF RISER TO FINISH GRADE OF PERVIOUS PAVEMENT.
3. ADD 1 AND 2 FOR DEPTH TO WATER TABLE.
4. NOTE IF B HAS CHANGED FROM PREVIOUS OBSERVATIONS (IF SHIFTING).



City of
Bellevue

STORM AND SURFACE
WATER UTILITY

TITLE

OBSERVATION PORT FOR
PERVIOUS PAVEMENT